



## Loop Listener

Our loop listener is a compact listening device for interaction with hearing aid induction loop systems.

It enables people to listen to a hearing loop system as if they were wearing a hearing device switched to the "T" position.

Our loop listener comes with headphones.

### Physical Data

Dimensions (boxed)	Height – 240mm (9.45") Width – 165mm (6.5") Depth – 40mm (1.58")
Weight	Weight – 0.25Kg (0.55lbs) with headphones
Construction	ABS Plastic

### Technical Data

Distortion	<0.5% THD @ 1kHz
Output Power	10mW @ 1kHz (16Ω)

### Applications

- To determine if a hearing loop system is functioning correctly
- For someone with hearing difficulty who does not wear a hearing aid
- If a hearing aid does not have a "T" function

### Features

- Flat frequency response
- Low cut filter
- More than 100 hours life with 2 x AAA batteries

Talk to us now:  
+44 (0) 1732 223900 (UK & ROW)  
+1 616 392 3400 (US & Canada)  
[www.contacta.co.uk](http://www.contacta.co.uk)

